

10

Abandoning Existing Infrastructure

10.1 MANHOLES

For manhole abandonment, plug all pipes with non-shrink grout, remove and dispose of manhole to 1.0 m below ground and fill with fillcrete.

10.2 CATCH BASINS

For abandonment of catch basins follow procedure for abandonment of manholes.

10.3 ABANDONED SERVICE CONNECTIONS

Abandoning existing service connections will be completed at property line. The water service CC is to be closed and the rod cut off 1.2m below finished grade. Sanitary services are to be disconnected at property line and cased in concrete. Documentation must be provided to the Town of Lamont referencing existing property pins, sidewalks, underground infrastructure, and other street furniture to properly locate the abandoned service.